

The implication of inhomogeneities in $\text{Li}_7\text{La}_3\text{Zr}_2\text{O}_{12}$ ceramics



Wachter-Welzl Andreas¹, Kirowitz J.¹, Wagner R.², Smetaczek S.¹, Bonta M.¹, Rettenwander D.³, Amthauer G.², Limbeck A.¹, Fleig J.¹

¹ Institute for Chemical Technologies and Analytics, Vienna University of Technology, Austria
² Department of Chemistry and Physics of Materials, University of Salzburg, Austria
³ Department of Materials Science and Engineering, Massachusetts Institute of Technology, USA



INTRODUCTION

Portable devices such as mobile phones, cameras, tablets, as well as electric vehicles rely on the availability of energy and so far Li-ion batteries are the most used energy storage system. A limiting factor for Li-ion batteries is the ion conducting organic electrolyte because of their chemical instability and flammability. Therefore, a lot of research focuses on replacing the organic electrolyte by solid state materials. Cubic $\text{Li}_7\text{La}_3\text{Zr}_2\text{O}_{12}$ (LLZO) garnets and its variants are among the most promising candidates for future Li-battery systems [1]. They provide a very high Li-ion conductivity and combine chemical and electrochemical stability. In this contribution, we present a combined study of

electrochemical impedance spectroscopy (EIS) and inductively coupled plasma mass spectrometry (ICP-MS) techniques on LLZO, to determine the effects of varying lithium and dopant content on the Li-ion conductivity. Besides overall conductivity measurements using blocking electrodes, measurements on microelectrodes of different size (20 – 300 μm) were performed to obtain information on local Li-ion conductivities. Within one and the same sample, conductivity variations up to almost one order of magnitude were found. Using laser ablation ICP-MS the local distribution of elements like Li, Zr, La, Al, etc. can be measured and correlated with variations in local conductivities.

EXPERIMENTAL

Impedance Spectroscopy




Figure 1 a) Sketch of the microelectrode (ME) measurement setup. b) The optical microscope image shows a part of the microelectrode array on top of a sample.

Parameters

Intended composition: $\text{Li}_{6.4}\text{Al}_{0.2}\text{La}_3\text{Zr}_2\text{O}_{12}$ Frequency: $3 \times 10^6 - 10^4$ Hz
 Electrode material: Ti (10 nm)/Pt (200 nm) Grain Size: ~ 150 μm
 Temperature: 23°C

LA – ICP - MS




Figure 2 Scheme of the Laser Ablation (LA) Ionized Coupled Plasma (ICP) Mass Spectrometry (MS) setup [2]

- 213 nm nanosecond LA system
- iCAP Q quadrupole mass spectrometer (MS)
- ImageLab used for data processing and image extraction

RESULTS

Microelectrode measurements




Figure 3 a) Impedance spectra obtained on microelectrodes with two different diameters (ϕ), and the corresponding fits (dashed lines). b) Sketch of the potential distribution in LLZO.

- High frequency semicircle corresponds to charge transport of lithium
- Differently sized microelectrodes investigate different volumes
- Small microelectrodes are more sensible to near surface phenomena




Figure 4 Local conductivities found for differently sized microelectrodes (σ_{me}) compared to the overall effective performance of the sample (σ_{macro}).

- Difference between σ_{me} and σ_{macro} is a factor two
- σ_{me} depends on the microelectrode diameter indicating surface near phenomena (degradation)

LA – ICP - MS




Figure 5 a) Intensity distribution, normalized to the zirconium signal, of the element a) lithium ($\frac{\text{Li}}{\text{Zr}}$) and b) aluminium ($\frac{\text{Al}}{\text{Zr}}$).

- Normalization to zirconium in order to diminish artefacts caused by the ablation
- Lithium distribution appears to be homogeneous
- Amount of aluminium decreases towards the outer rim

CONCLUSION

- Local conductivity measurements using microelectrodes were successfully achieved on LLZO
- Conductivity of microelectrodes depends on the diameter
- Local impedance measurements reveal the existence of conductivity variations (higher conductivities near the outer rim)
- ICP measurements show inhomogeneous aluminium distribution, indicating that variations in local conductivity are related to stoichiometric changes

OUTLOOK




Figure 6 Sketch of measurement results when combining LA-ICP-MS and microelectrode measurements

- Combining quantitative LA-ICP-MS and microelectrode measurements will allow to find the stoichiometry with the optimal ionic conductivity
- Depth profiling will give further information on the overall distribution of elements
- accurate analysis of the composition will help to improve preparation routes

References

- [1] R. Murugan, Wiley 2007, 46, 7778
- [2] R. E. Russo, Talanta, 57, 425-451, 2002

Contact Information

Andreas.Wachter-Welzl@tuwien.ac.at
 TU-Wien - Institute for Chemical Technologies and Analysis
 Getreidemarkt 9 - 1060 Wien
 AUSTRIA



The authors gratefully acknowledge The Austrian Research Promotion Agency (FFG), SoLiK project, for financial support.